CONTENTS PAGE

24"

47"

16"

PARTS LIST

**BMX Jump**
1 - Panel
1 - Toe piece
2 - Legs
2 - Rubber feet
1 - Support plate
2 - 3" bolts
20 - 2" bolts
44 - Small washers
22 - Lock nuts
2 - Leg plates
2 - Hinges

BMX Roller
1 - Roller Panel
4 - J-bolts
8 - 2" bolts
16 - Small washers
4 - Big washers
4 - Wing nuts
8 - Lock nuts
4 - Hinges

BMX JUMP INSTRUCTIONS

TOE PIECE

STEP 1

Place the toe piece on one of the ends of the ramp aligning the holes in the toe piece with the holes on the ramp

BOLTING

STEP 2

Place the bolts through the toe piece and the ramp

Then place a washer and then a nut and tighten them

LEG PLATES

STEP 3

Align the leg plates on the sides of the ramp with the holes at the ends of the ramp as shown

LEG PLATES

STEP 4

Secure the leg plates to the ramp by placing a bolt through the ramp and then the leg plate

Follow it by a washer and then a lock nut

BOLTING LEGS

STEP 5

Secure the legs to the ramp by placing a bolt through the ramp and then the leg

Follow it by a washer and then a lock nut

BOLTING LEGS

STEP 6

To make the legs stronger use the leg support bracket and bolt it using the holes in the legs as shown

Secure the legs to the plate by placing a bolt through the ramp and then the leg

Follow it by a washer and then a lock nut

BOLTING LEGS

STEP 7

Secure the leg in the desired setting on the plate by placing a bolt through the plate and then the leg

Follow it by a washer and then a lock nut

Use this hole for assembling the hump ramp

BMX ROLLER INSTRUCTIONS

HINGES

STEP 1

Place the hinges on the ends of the ramp and hump where the 2 holes are

Alight the holes in the hinge with the tabs facing outward as shown

HINGES

Connect the hump ramp with the ramps
by the hinges

HINGES

STEP 3

Connect the hump ramp by placing a long bolt through the hinges and following it with a washer and lock nut